

LE-76CJ LE-86CJ LE-156CJ LIQUID HANDLING ASSEMBLIES

CAUTION

When pumping chemicals, make certain that all tubing is securely attached to the fittings. It is recommended that tubing or pipe lines be shielded to prevent possible injury in case of rupture or accidental damage. Always wear protective clothing when working on or near chemical metering pump.

MATERIALS OF CONSTRUCTION

Seal Rings	Teflon
Balls	Stainless Steel
Head	Acrylic
Liquifram	Teflon Face
Suction	.938 O.D. Vinyl
Springs	Stainless Steel

A. FLOODED SUCTION (PREFERRED METHOD)

1. Mount pump 12" above floor with head extending beyond mounting so suction tubing curves gently away from pump to prevent kinking.
2. Install 1/2" or 3/4" shut off valve, with at least 3/4" clear way through the valve, into reservoir. This is necessary to stop flow from reservoir while servicing pump.
3. Install barbed connector (one of two supplied) into valve. Attach 15/16" O.D. Vinyl tubing to barbed connector; secure with hose clamp provided (use shortest length of suction tubing practical).
4. Connect other end of suction fitting at pump and secure with hose clamp provided.

B. SUCTION LIFT (PUMP SITTING ON BARREL : MAXIMUM LIFT 3.5 FT.)

1. Connect suction tubing to barbed suction fitting on pump. Secure with hose clamp provided.
2. Cut tubing so it will only reach within 1" of bottom of barrel.
3. If tubing curl is a problem fabricate 1" Polypropylene pipe as tube straightener (pipe should be slightly longer than depth of barrel for ease of removal).
4. Place tubing straightener over suction tubing and lower into barrel.

C. PRIMING

1. Pump is shipped pre-primed with water. If pump has lost its water prime, pre-prime with water using 100% stroke and 50% speed setting.
2. Make final installation except for injection connection at far end of tubing.
3. Open valve in suction line if installed.
4. Set pump at 100% stroke length and 50% speed. Start pump.
5. After all air is expelled from head, connect tubing at far end to connector. Open valve at injection point if installed. Adjust discharge rate to desired amount using longest stroke and slowest speed practical.
6. If difficulty is experienced on initial prime apply vacuum to discharge tubing by suitable means, such as hand suction pump. This should not reoccur after pump is primed with a viscous liquid.



LIQUID METRONICS INCORPORATED

19 CRAIG ROAD · ACTON, MA 01720-5495, U.S.A. · (508) 263-9800 · TELEX 95-1781 · FAX (508) 264-9172

Replaces Same of 8/88
1384.C 11/88

KEY NO.	PART NO.	DESCRIPTION	QUANTITY		
			LE-76CJ	LE-86CJ	LE-156CJ
4	25042*#+	Ball, Stainless Steel	2	2	2
6	25128*#+	Seal Ring, Teflon	2	2	2
10	30089	Head Asm	1	0	0
10	30091	Head Asm	0	1	0
10	30261	Head Asm	0	0	1
12	29743 26033	Valve Housing, PP	1	1	1
14	10340	Screw	4	4	4
15	25540	Head, 1.8	1	0	0
15	25550	Head, 0.9	0	1	0
15	28390	Head, 0.5	0	0	1
16	10305*	Liquifram, 1.8	1	0	0
16	10302#	Liquifram, 0.9	0	1	0
16	29742+	Liquifram, 0.5	0	0	1
17	25558*#+	Spring, SS	2	2	2
18	25649	Valve Seat, Barbed	1	1	1
19	25636-3.5	Tubing, Vinyl, .938" OD	1	1	1
20	25650	Connector, Barbed, 1/2" NPT	1	1	1
21	25652	Hose Clamp	2	2	2

+ Parts included in Spare Parts Kit SP-156CJ
 * Parts included in Spare Parts Kit SP-76CJ
 # Parts included in Spare Parts Kit SP-86CJ

NOTE:
 Threaded connections into pump head are 1"-12 straight threads. DO NOT USE TEFLON TAPE. These joints are sealed by seal ring valve seats (item 6 on exploded view).

