

Milton Roy AutoPrime Kit

10895 1/2 Tube to
1/2 MNPT connector

37769 Valve Housing
37203 Clamp Ring
10411 Coupling Nut

38538 AutoPrime Valve*

N-MRADAPT
AutoPrime Adapter

Remove ball check from existing check
valve and reinstall fitting in pump head.

M Roy w/ 1/2"
MNPT

Not to scale

