





4-FUNCTION VALVE (4FV)




3-FUNCTION VALVE (3FV)



4-FUNCTION BLEED VALVE (B-4FV)



Washer on Bottom
Install 3-piece cartridge valve as shown in direction of flow arrow



Washer on Top
Install 3-piece cartridge valve as shown in direction of flow arrow

